


Thank you for purchasing the RichardSolo 20800 mAh 3-Port Power Bank. Please read these instructions before operation and save for future reference.



- 1 USB output port 1 (5V 1A)
- 2 USB output port 2 (5V 1.5A)
- 3 USB output port 3 (5V 2.1A)
- 4 Micro-USB input port (5V 1.5A)
- 5 LED flashlight
- 6 Power button
- 7 4 LED charge capacity indicators (25%, 50%, 75%, 100%)

Charge 20800 3-Port Power Bank:

- 1 Connect included USB/micro-USB cable to Power Bank micro-USB input port (4).
- 2 Charge via any powered USB port. Use AC/USB adapter (not included) for faster results.
- 3 LEDs (7) flash in 25% increments and remain solid when corresponding capacity* is reached.

**Note: LEDs may not provide an accurate reading while battery is recharging. For optimum performance, make sure all LEDs have stopped flashing and remain solid to ensure full charge capacity. Total recharge time from 0% - 100% = +/- 14 hours.*

Charge your device:

- 1 Connect USB charge cable included with your device to Port 1, Port 2, or Port 3.
- 2 Press power button (6) to begin charging. Monitor charge status via screen icon on your device.
- 3 Use Port 1/Port 2 for iPhone, iPod, iPad Mini, smartphones, and smaller 1A devices.
- 4 Use Port 3 for iPad and larger 2.1A devices.
- 5 To stop charging, remove cable from your device.

**Note: Power Bank LEDs remain lit while device is charging and show remaining battery capacity. When no connection is detected for 20 seconds, Power Bank shuts off. When device is fully charged, Power Bank will trickle charge device until Power Bank is disconnected or completely discharged.*

Tandem charge* (charge Power Bank/device simultaneously):

- 1 Connect your own USB cable from device to Power Bank Port 1, Port 2, or Port 3.
- 2 Press power button (6) to begin charging.
- 3 Connect included USB/micro-USB cable from AC/USB adapter to Power Bank input port (4).
- 4 Device charges first followed by Power Bank.
- 5 Monitor charge status for device on its screen.
- 6 Monitor charge status for Power Bank via 4 built-in LEDs (7).

**Note: total recharge time is longer in tandem mode.*

Check remaining charge capacity / Use LED flashlight:

- 1 Press power button (6) once to check remaining Power Bank charge capacity. 1 LED flashing = less than 25%; 1 LED solid = about 25%; 2 LEDs = about 50%; 3 LEDs = about 75%; 4 LEDs = about 75-100%.
- 2 Press power button (6) twice to illuminate built-in LED flashlight (5). Press twice to switch off.

USB Compatibility

Port 1 (1A): iPhone/iPod, smartphones, MP3 players (standard charge)

Port 2 (1.5A): iPhone/iPod, smartphones, MP3 players (slightly faster charge)

Port 3 (2.1A): iPad/tablets + iPhone/iPod, smartphones, MP3 players (best for larger devices)

Maintenance

- 1 Do not store in a depleted state — battery power cells can be damaged. Charge Power Bank at least once per month when not in use.
- 2 Keep unit dry — avoid damp conditions and corrosive materials.
- 3 Do not clean with harsh chemicals, soaps or detergents.

Specifications

Capacity: 20800 mAh
Cell Type: Li-ion battery
Input: DC 5V 1A
Port 1 Output: DC 5V 1A
Port 2 Output: DC 5V 1.5A
Port 3 Output: DC 5V 2.1A
Size: 0.87" x 3.15" x 6.3"
Weight: 15.1 oz. (429 gr)

Package Contents

- 20800 mAh 3-Port Li-ion battery
- USB/micro-USB charge cable
- Instructions

Safety Instructions

Read all instructions and warnings prior to using this product. Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or other hazard causing serious and/or fatal injury and/or property damage.

- 1 Do not modify, disassemble, open, drop, crush, puncture or shred this product.
- 2 Do not expose this product to rain or water.
- 3 Avoid excessive heat (open flame, sunlight, etc.).
- 4 Keep away from high voltage devices.
- 5 This product is not a toy — keep away from children.