

RichardSolo Simply AM/FM Radio

Setting Your Clock

To set the clock on the Simply Radio, you first remove the clock and adjust the time by rotating the circular wheel on the rear of the clock itself. If your clock is not yet running, you remove the paper tab from the button battery compartment, also on the rear of the clock.

To remove the clock from the radio:

1. Grip the raised notches located on the outer rim of the clock at the 3 and 9 o'clock positions.
2. Gently rotate the outer rim of the clock counter clockwise just a few nudges where it will stop.
3. Then slip your fingernail beneath the rim and ease it out.

It's basically just a small counter-clockwise turn of the clock and the entire unit pops out. To reinstall, you place the unit back in its slot in the exact position where it was removed. You then twist the unit clockwise so that 12 o'clock lines up where it belongs:

